

Digital Fireproof Safes

Please remember: at no stage should any of the safe's keys be inside of the safe when closed.

Instructions:

- 1) For the first use, use the over-ride key + the main key to open the safe
- 2) Once the safe is open, you will be able to find the battery compartment on the top edge of the door. Insert 4x AA batteries.
- 3) Now press the green button on the inner inside edge of the door. This will allow you to set your passcode.
- 4) Enter your desired 1-8 digit passcode and then press “#”
- 5) Your safe setup is now complete. From this point, to open the safe you will need to have the main key inserted and turned, press “#”, enter your code, then press “#” again to finalize.