

Fireproof Gun Safes

Please remember: at no stage should any of the safe's keys be inside of the safe when closed.

Instructions:

- 1) Twist the keypad housing counterclockwise to reveal the battery/over-ride key compartment.
- 2) Insert the battery and then use the over-ride key to open the safe for the first time
- 3) Press the green button located on the inner inside edge of the door. This will allow you to set your passcode.
- 4) Enter your desired 1-8 digit passcode and then press "*"
- 5) Your safe setup is now complete. From this point, to open the safe you will need to enter your passcode and then press "#"