

# Gun Safes

**Please remember: at no stage should any of the safe's keys be inside of the safe when closed.**

## Instructions:

- 1) Ensure that the dial to the left of the keypad is in its clockwise position
- 2) Remove the small plastic cover between the dial and the keypad. This will reveal the keyhole for the over-ride key.
- 3) For the first use, use the over-ride key to open the safe
- 4) Once the safe is open, you will be able to find the battery compartment on the inside of the door. Insert 4x AA batteries.
- 5) Now press the red button near the battery compartment. This will allow you to set your passcode.
- 6) Enter your desired 1-8 digit passcode and then press "E"
- 7) Your safe setup is now complete. From this point, to open the safe you will need to Press "E", enter your code, then press "E" again to finalize.